



Installation Guide

1. System must be turned OFF. Connect the Embedded IDE-CF adapter to the 40-pin IDE connector on the motherboard.
2. Connect the 2-Pin power connector side of the Y-type power cable to this adapter and the other end to the PC power supply.
3. Insert a CF card or Micro Drive before the turning the system ON.

v4.1.11

Technical Support

If you need any assistance to get your unit functioning properly, please have your product information ready and contact Addonics Technical Support at:

Hours: 8:30 am - 6:00 pm PST

Phone: 408-453-6212

Email: <http://www.addonics.com/support/query/>