

Sliding Rails Installation Instructions

This is the procedure to install the Addonics Storage Rack chassis into a 4U-compatible rackmount equipment using the [Addonics Sliding Rails](#) (SRRAIL).


You will need the following items:

- Addonics Storage Rack or other rackmount device
- 4U-compatible rackmount equipment
- Large Phillips (cross-shaped) screwdriver
- Addonics Slide Rail and included accessories (see images below, click for enlarged view)




Installation Procedure:

1. Fully extend **Slide Rail** so that **Inner Rail** segment is protruding.



2. On the **Inner Rail** segment, locate disconnection latch. While the latch is held, pull the **Inner Rail** segment away from the rest of the **Slide Rail** to detach it.



3. Hold **Inner Rail** against rackmount chassis and secure it using the included **Small Screws** or **Large Screws**, depending on the type of screw the rackmount chassis accepts. Repeat the process on the opposite end of the the rackmount chassis, making sure the two **Inner Rails** are aligned.



4. Turn the **Slide Rail** over to where the screw holes are located. Using the **Small Screws**, fasten one **Rail Bracket** to each side of the **Slide Rail**, positioning according to the distance between the rack frames on the rackmount equipment. It may be worthwhile to keep the screws loose at this point so that the **Rail Brackets** can be positioned accurately during actual installation. Repeat this step for the other **Slide Rail**.



5. On the rackmount equipment, secure the L-shaped edge of the **Rail Bracket** onto one of the front rack frames, using screws included with the rackmount equipment. On the rear end of the rackmount equipment, secure the other **Rail Bracket** onto the rear rack frame. Repeat this step for the other side of the rackmount equipment.



6. Once both sides of the **Slide Rail** have been installed onto the rackmount equipment, insert the rackmount chassis by aligning the **Inner Rail** and the **Slide Rail** on both sides. The disconnection latch must be held on both **Inner Rails** in order for the chassis to be fully inserted inside the **Slide Rail**.



This instruction can also be viewed at http://www.addonics.com/support/faqs/faq_install_sliderail.asp